



Replacement Instructions

1. Follow general instructions on back of pouch. Read instructions through before beginning installation. Have someone to hold and support the hood, hatch, liftgate or trunk while replacing the old lift supports.
2. Remove ball stud from the vehicle body using an open-end wrench.
3. Install the provided ball stud into vehicle body.
4. Remove bracket and old lift support.
5. Install the new bracket using the original hardware.
6. Install nylon bushing in eyelet of new lift support.
7. Using the provided mounting stud, washers, and e-clip, attach the bracket to the eyelet end of the lift support.
8. Press the plastic end fitting onto the ball stud located on the vehicle body.
9. Check that all connections are tight and secure.