

Replacement Instructions

1. Follow general instructions on back of pouch. Read instructions through before beginning installation. Have someone to hold and support the hood, hatch, liftgate or trunk while replacing the old lift supports.
2. Install provided ball stud and nut into new bracket with the same orientation as the original rod end bracket.
3. Cut the electrical wires close to the connections on the original lift support. Strip wire insulation and crimp new electrical terminals onto each wire.
4. Remove factory lift support from the vehicle. Keep the original hardware for use on new installation.
5. Install provided ball stud into vehicle body using original washers as spacers.
6. Install new bracket assembly onto vehicle using original mounting bolts.
7. Install the new lift support on vehicle in the same orientation as the original lift support reusing original mounting hardware.
8. Attach electrical terminal to new lift support.
9. Check that all connections are tight and secure.