

Replacement Instructions:

1. Follow general instructions on back of pouch. Read instructions through before beginning installation. Have someone to hold and support the hood, hatch, liftgate or trunk while replacing the old lift supports.
2. Remove the tube-end of the old lift support from hood using an open-end wrench.
3. Remove the rod-end bracket and old lift support from vehicle. Note the direction of the bracket on the vehicle.
4. Remove the rod-end mounting bracket from the old lift support by drilling out the rivet. After drilling out rivet, drill out the hole to an 8mm diameter.
5. Attach the new lift support to the bracket using the supplied hardware: 1) insert pin through the underside of the bracket, 2) place lift support eyelet over pin, 3) Insert e-clip in pin groove.
6. Install rod-end mounting bracket to the vehicle using the original screws.
7. Press the plastic end fitting onto the ball stud to install the tube-end of the new lift support.
8. Check that all connections are tight and secure.