



Replacement Instructions:

1. Follow general instructions on back of pouch. Read instructions through before beginning installation. Have someone to hold and support the hood, hatch, liftgate or trunk while replacing the old lift supports.
2. Remove the tube-end mounting bracket from the vehicle body by unbolting.
3. Install the provided ball nut and washer onto the lower body threaded stud.
4. Remove the original ball stud and lift support from the glass window. Save original hardware.
5. Install the provided ball stud and the original hardware onto the glass window.
6. Install the new lift support in the same direction as the original lift support by pressing the plastic end fitting onto the ball nut and ball stud one side at a time.
7. Check that all connections are tight and secure.