



Replacement Instructions:

1. Follow general instructions on back of pouch. Read instructions through before beginning installation. Have someone to hold and support the hood, hatch, liftgate or trunk while replacing the old lift supports.
2. Remove rod-end of the existing lift support from the ball stud on the hatch.
3. Remove tube-end bracket and existing lift support from vehicle by unbolting the two screws.
4. Remove the bracket from the lift support by drilling out the rivet. Enlarge the bracket hole to 5/16" diameter.
5. Attach the new lift support to the supplied bracket using the new hardware: 1) Insert pin through bracket, 2) Position lift support eyelet over the pin, 3) Install washer over pin, 4) Install e-clip in the pin groove.
6. Install the tube-end mounting bracket to the vehicle using the original mounting screws.
7. Install the rod-end of the lift support by pressing the plastic end fitting onto the ball stud.
8. Check that all connections are tight and secure.