

Replacement Instructions

1. Follow general instructions on back of pouch. Read instructions through before beginning installation. Have someone to hold and support the hood, hatch, liftgate or trunk while replacing the old lift supports.
2. Remove the old lift support from the vehicle. Keep original hardware for use on new installation. Note the orientation of the factory bracket on the vehicle.
3. Remove the tube-end mounting bracket from the old lift support by drilling out the attachment rivet.
4. Install the provided ball stud and nut onto the bracket in the same orientation as the factory rivet and install the bracket on the vehicle.
5. Place the provided bushing into the eyelet of the new lift support, then place the provided nylon washer on the other side of the eyelet.
6. Install the original washer on the original mounting bolt, and attached the rod-end eyelet of the new lift support to the vehicle.
7. Install the tube-end of the spring by simply pressing plastic end fitting onto the bail stud.
8. Check that all connections are tight and secure.